



NEMO QUALITY

There is a reason why our logo resembles a medieval shield. If you've ever seen an authentic medieval shield or piece of armor, the detail and quality of craftsmanship are astonishing. Hours were spent shaping and perfecting every component knowing the gravity of purpose and the need for reliable performance. At NEMO, we take the same approach to quality. We know from our own experience how vital a tent can be for comfort and survival. Your tent is your home in the wilderness and your armor against the elements. We obsess over every design decision to ensure you get the greatest comfort and protection possible. Our process begins with pencil and paper and evolves methodically through computer modeling, prototyping, testing and development. We use all the latest tools, software, manufacturing methods and materials. If we aren't happy with what's available we make our own. We strive to design and build the best tents on the planet. We stand behind our shield, the symbol of NEMO quality.


To learn more, please visit our website at www.nemoequipment.com.

LOSI™ 3P

Comfort. Strength. Versatility.


Your tent is your home in the wilderness, so don't sacrifice comfort and stability for a few ounces. We've used the lightest weight materials and a unique pole structure to build Losi™ 3P extra sturdy and extra spacious without tipping the scales. Two doors and two large vestibules provide plenty of extra room to share. An optional machine washable Pawprint™ liner snaps inside the tent so you can enjoy a clean and soft place to rest on every trip. On nice summer evenings, keep the rain fly off to enjoy the full mesh canopy. On rainy nights, the fly has openings at both ends of the tent to keep air circulating. Losi™ 3P offers you the most space and comfort possible in the under 6 lbs category.

Capacity:	3
Minimum Weight:	5.9 lbs / 2.68 kg
Packed Weight:	6.7 lbs / 3.04 kg
Frame:	4 DAC 9 / 9.6 mm Featherlite Easton Carbon FX Upgrade
Tent Fabrics:	Mesh / 30 D Sil-PU Nylon
Floor Dimensions:	91" x 79" / 231 x 201 cm
Interior Height	47" / 119 cm
Floor Area	50 sq ft / 4.64 sq m
Vestibule Area:	26 sq ft / 2.42 sq m
Total Area Under Canopy:	76 sq ft / 7.06 sq m




LOSI™ 3P
3 PERSON

Losi™ 3P Inner Tent



1. Main Poles (Aluminum or Carbon Fiber Upgrade)
2. Ridge Poles (Aluminum or Carbon Fiber Upgrade)
3. Mesh Canopy
4. Swivel Hub
5. Swivel Clips
6. Jake's Foot Pole Anchors
7. Dual Side Doors
8. Side Door Tie-Back
9. High Splash Guard Floor


Losi™ 3P Tent with Fly




10. Overlap Vent in Rain Fly
11. Door Tie-Back
12. Vestibule Door
13. Jake's Foot Fly Attachment

NEMO Innovation


1. **Unique Pole Configuration:** the ridge poles on Losi™ 3P run the long direction on the tent and end above the ground. This design adds significant strength and provides nearly vertical walls on all sides of the tent. The steep walls mean you can sit straight up almost anywhere inside Losi™ 3P.




2. **Superior Hardware:** several innovative pieces of hardware are used to increase the ease of setup and strength of Losi™ 3P.



The Jake's Foot anchor system from DAC makes tent setup faster and easier. The main poles attach to the anchors by ball and socket. When the fly is attached, the Jake's Feet act as cantilevers to pull the corners of the inner tent closer to the ground.




The swivel clips and center swivel lock the poles together at their intersections. This makes the tent much stronger.



The unique shape of the DAC pole clips makes them easy to use and more durable than standard pole clips.

3. **3P Pawprint™:** (sold separately) this interior liner is made of abrasion resistant, brushed nylon fabric that is very soft and totally machine washable. Now you can have a clean, soft place to sleep on every trip. If you'd like to bring the dog along, Pawprint™ will keep your dog's paws from tearing up the tent floor.




4. **Light Pocket™:** most headlamps have a focused beam and hanging your lamp inside your tent can be frustrating. To make things easier, Losi™ 3P includes a special pocket for your headlamp with a light diffusing fabric. Place your lamp in the pocket with the light facing towards the inside of the tent, and the Light Pocket™ will help cast an even light throughout the tent.





Tent Setup

1. Lay out the contents of Losi™ 3P and make sure that you received all of the following items: rain fly, inner tent, stuff sack, removable gear pocket inside the tent, two main poles with swivel, two shorter ridge poles, eight pegs, guy-lines, pole repair sleeve, Tear-Aid® fabric patch, and an extra Jake's Foot.




2. When choosing a location to pitch your tent, select a flat area free of fragile undergrowth and sharp objects. Losi™ 3P is a freestanding tent which means it will still function without being staked out. For full strength, stake the corners of your tent to the ground with the included pegs. If the ground is too hard to place pegs, tie the corners of your tent to heavy objects like rocks. If you are forced to set up your tent on an incline, face the front of your tent uphill.

3. Attach the ends of the main poles to the corner anchors of the tent so the poles cross in the middle. Make sure the button clip part of the swivel faces down. The Jake's Foot anchors will lock the pole ends in place.




4. Clip the black piece of hardware at the top of the tent to the bottom of the clear swivel on the main poles. Clip the rest of the tent to the poles with the clear clips.

5. Insert the ridge poles through the side pole sleeves and into the grommets on the sides of the tent. Keep the ridge poles on the outside of the main poles. Use the finger loops to help pull the webbing on and off of the pole tips.




6. Connect the ridge poles to the main poles with the black swivel clips. With one hand, align the main pole in the bottom cradle. With your other hand, pull the double clips over the ridge pole.



7. Lay the fly over the inner tent with the shiny side down. Align the seams with the poles and clip the corners to the ends of each Jake's Foot. Place the grommets over the ends of the ridge poles using the finger loops to help.

8. Stake out the vestibule anchors. Adjust the webbing straps on each anchor to create an even tension throughout the entire tent.



9. In extreme weather, attach the supplied guy lines to the reflective guy-out loops and stake in place.

10. Place your headlamp in the Light Pocket™ to create an even glow inside your tent.



Accessories (Sold Separately)

Several accessories are available for Losi™ 3P to add comfort or longevity to your tent.

Footprint

To install the Losi™ 3P Footprint, slip the split rings over each of the four corresponding corner anchors. This will protect the floor of your tent from abrasion and add to the lifespan of your tent. Make sure the Footprint is not exposed under the tent shell or it could collect water in a rain storm. By moving the Jake's Feet to your Footprint, you can set up a very lightweight shelter as shown below.




Easton Carbon FX Pole Upgrade

These carbon fiber poles are the lightest and strongest on the market. The FX poles install exactly the same as the standard poles, but add even greater rigidity to the tent while reducing the weight by a few ounces.


3P Pawprint™

To install the Pawprint™, snap its corners to the snaps in the inside corners of the tent. The Pawprint™ can stay attached to Losi™ 3P when the tent is packed. If you want to remove the Pawprint™, use the finger loops to help unsnap the corners.



Tent Take Down


1. To take down Losi™ 3P, first remove the fly by twisting off the corner clips and pulling on the finger loops to release the poles from the grommets. Shake off any moisture. Water will add weight to your pack and can lead to mildew.



2. Empty the inner tent and remove accessories (including the Footprint and Pawprint™). Shake out moisture and debris. Remove the ridge poles from the grommets using the finger loops. Unclip the swivel clips and other pole clips.

3. Twist the Jake's Foot anchors to remove the main poles. Fold all of the poles and store them in the pole pocket of the stuff sack.

4. With your foot on the accessory pocket of the stuff sack, stuff the tent and fly into the large mesh pocket.



5. Roll up the stuff sack, securing it with the compression straps. The Losi stuff sack also works very well as a hanging drying bag when not in carrying the tent.

6. Remember to leave no trace even in winter. Before leaving your campsite take a thorough look around making sure you have not left anything behind, out of place, or damaged.

Storage

Remember to dry your tent out completely before storing as moisture can lead to mildew. Also try to remove as much dirt and debris from your tent as possible. Avoid storing your tent compressed or exposed to UV light for long periods.



Tips for Extending the Life of Your Tent

- △ Avoid rough ground, especially rocks and pavement.
- △ Make sure the tent is clean and dry before packing.
- △ Store the tent unpacked to allow air circulation.
- △ Occasionally inspect the tent for wear and tear.
- △ Don't store the tent exposed to UV light.

Fabric

- △ "My tent has a mildew smell."

Always pack and store your tent dry! Mildew is not only smelly and bad for the tent materials, it is also unhealthy. Contact Rainy Pass Repair (see below) for advice about safely removing mildew.

- △ "I sliced my tent on a sharp tree branch!"

We use a ripstop weave pattern to prevent tears from expanding in the fabrics, but tears can happen. Make sure the area you choose to set up your tent is free of sharp rocks, sticks, or thorns. Take care when using any sharp tools near your tent! Remember that your tent is your home in the mountains and it's made of lightweight fabric. Small tears in the fly can be reinforced with the included Tear-Aid patch on the inside of the fabric. The Tear-Aid will only stick well to the inside of the fly. Larger areas can be hand-stitched and sealed with Seamgrip®, or you can send your tent to Rainy Pass for repair. (See information below).

Jake's Foot

△ "I've broken my corner anchor!"

The Jake's Foot corner anchors are made to be rugged enough for any adventure. However they are plastic parts and can be broken under extreme stress. The Jake's Foot is also made to be removable to convert Losi™ 3P to an "On the Fly" shelter when connected to its footprint. Your tent came with an extra Jake's Foot in case one is ever lost or broken. To assemble the anchor, first pull the tri-glide along the webbing so it rests against the tent. Loop the webbing up and around the widest bar at the end of a Jake's Foot. Run the tail of the webbing back through the tri-glide.

Poles

△ "A tree fell on my tent and one of the poles was broken!"

First, make sure you are OK, and then direct your attention to the tent. The best way to fix a broken pole is with the repair sleeve that came with your tent. If the pole is cracked or broken cleanly, the repair sleeve should slide in place over the damaged area. If the pole is bent or has a burr around the break, it may be necessary to cut or file the damaged area. A temporary fix may be possible by taping another pole or extra tent stake alongside the damaged area. Contact NEMO to order replacement poles.



NEMO Repair

If you have any problems with a NEMO product, please contact Rainy Pass Repair, Inc., the industry leader in outdoor product care for repair or replacement. If you have any questions regarding warranty and repair, or if you need to send a product in for service, please call Rainy Pass. It is not necessary to clean the item before sending, but it will be appreciated if you remove any excessive soiling. Rainy Pass will be happy to give you advice about safely cleaning your product. Please provide the following when you send a NEMO product to Rainy Pass:

- △ A note with your name, phone number, address, e-mail and problem description. A repair form can be downloaded at:
www.nemoequipment.com/pdf/NEMO_repairform.pdf
- △ Mark all damaged areas on the product with masking tape.
- △ Pack the product in a sturdy cardboard box with plenty of room. If possible, use the original box to reduce waste.

Ship to:
Rainy Pass Repair, Inc.
5307 Roosevelt Way, NE
Seattle, WA 98105

To contact Rainy Pass:
Phone: 1.888.747.7867
Email: repair@rainypass.com
www.rainypass.com

NEMO Warranty

NEMO guarantees every product we sell. We put a great effort into choosing the best materials and providing you with the highest level of workmanship. If one of our products does not meet your expectations during its useful life, we promise to repair it, replace it, exchange it, or give you a refund at our discretion. NEMO does not warranty products against normal wear and tear, unauthorized modifications or alterations, improper use, improper maintenance, misuse or neglect or if the product is used for a purpose for which it is not intended. Except as expressly set forth in these terms and conditions, NEMO is not liable for any direct, indirect or consequential damages arising out of or resulting from the use of a NEMO product. The warranties set forth in these terms and conditions are in lieu of all other warranties, express or implied, including without limitation, implied warranties of merchantability or fitness for a particular purpose.







NEMO Green

Our spirit is in adventure. Without the beautiful wild places where adventures are made, our spirit dies. Please join us in protecting the planet and preserving the places where our spirit thrives.

NEMO is a small company but even small companies and individuals can make a difference. Here are some of the green efforts we are currently making:

- ⏏ NEMO employees get one day off every month to pursue a green effort or help with a community cause.
- ⏏ NEMO adopted the northern end of Jenness Beach in North Hampton, NH through the Blue Ocean Society. The adoption enables NEMO to keep the beach clean throughout the year and also track the types of debris to determine whether the trash is ocean-based or land-based.
- ⏏ We sell or donate our old samples to other companies to cut up and make new products.
- ⏏ NEMO donates tents to college outing clubs to encourage students to get outdoors and foster a love for the environment.
- ⏏ We recycle everything possible in our shop and encourage our partners to do the same.
- ⏏ We reuse packaging materials whenever possible.
- ⏏ We do as much of our printing as possible on recycled paper with environmentally-friendly inks.
- ⏏ As of 2006, we don't use any PVC in our products.
- ⏏ As of 2008, all of our aluminum poles from DAC use a new more environmentally-friendly anodization process.
- ⏏ All of our business partners domestically and overseas run responsible businesses with good working conditions and respect for the environment.
- ⏏ NEMO makes donations to many groups such as the Access Fund and the National Wildlife Federation to help preserve the natural places we cherish. We have also donated tents to help with disaster relief, including donating over 150 winter mountaineering tents to Pakistan in 2005 following the earthquake in Kashmir.



Never place your stove, campfire, or other flame source in or near your tent. Never cook, light, or refuel a stove or any other heat source inside your tent. Death by suffocation and/or serious burns is possible.	Maintain adequate ventilation inside your tent at all times. Death by suffocation is possible.	Anchor your tent properly at all times to reduce the risk of loss or injury to the tent or occupants.	Carefully consider the possibility of falling rocks or tree limbs, lightning strikes, flash floods, avalanches, strong winds, and other hazards when choosing a campsite to reduce the risk of loss or injury.
NO FIRE	VENTILATION	ANCHOR	CAMPSITE
			



WARNING

If you have additional questions, please contact
NEMO Equipment, Inc. directly at 800-997-9301
www.nemoequipment.com

NOTE: All 2008 NEMO tents meet the CPAI-84 standard for flame retardancy.





NEMO MISSION

Our 2008 product line is the result of 6 years of devoted labor and half a million years or so of developing better tools for shelter and survival. NEMO is about what we have just discovered and what we have known for a long time. It's about beautiful design and intelligent engineering. It's about serene cloudless days and bitter cold nights spent battling snow drifts and frostbite. It's about bringing two worlds together: the world of design and technology and the actual world where we test ourselves and our inventions. We are pursuing perfection. It is an epic journey, often elusive, demanding youthful energy, creativity and courage. We have come a long way in our travels and we promise never to yield in our determination. Like our ancestors who explored new places for the first time, we will change the common idea of what is possible.

Please visit us at: www.nemoequipment.com

NEMO EQUIPMENT, INC.
100 FACTORY ST, NASHUA, NH 03060
P: 800-997-9301 F: 603-881-9358



Printed on Recycled Paper



www.nemoequipment.com

©2008 NEMO Equipment, Inc.