



MOKI™ VESTIBULE

Moki™ is your ultimate base camp shelter and that can mean a lot of extra gear. For extra storage options, add a second vestibule to your tent. This vestibule is identical to the one included with Moki™, and adds an extra 12 square feet of protected space. The vestibule features multiple entrances, a UVX weather-checking window, and additional guy-out loops for extreme weather conditions. Vestibules can be used on either door.



Minimum Weight (with pole):	1.7 lbs (0.8 kg)
Packed Weight (with pole):	1.8 lbs (0.8 kg)
Frame:	DAC 9.6 mm Featherlite® NSL
Fabric:	30D PU Nylon
Interior Height:	40" (102 cm)
Floor Area:	12 sq ft (1.1 sq m)


MOKI™ VESTIBULE

FITS MOKI™ 3 PERSON TENT




Setup Guide

1. Zip the upper vestibule panel to the vestibule. **NOTE: Be sure to use the upper vestibule with zipper flap, not the Connection Panel with red Velcro®.** Slide the vestibule pole through the pole sleeve. Attach the end tips to the grommets in the vestibule and tent anchors, and tighten webbing to hold vestibule in place. Zip the upper vestibule to the tent.



2. Stake your vestibule while it is zipped closed. Place the stake through the anchor and adjust the webbing for proper tension.



3. In extreme weather, attach the supplied guy lines to the guy-out loops and stake in place. In high winds, it is best to face the main doors or vestibule into the wind.



4. The full-size vestibule provides plenty of additional space for gear storage and a dry entry during bad weather. On sunny days, the vestibule is easily removed by unzipping it from the tent. Remember you should never cook inside your tent.





More Moki™ Accessories

1. **Moki™ Pawprint™:** The Pawprint™ is a removable liner for the inside of your tent. It has the dual function of protecting your tent floor from boots and paws, and of adding serious comfort. The Pawprint™ is made of a machine-washable brushed fabric that is very soft to the touch. With a clean, soft Pawprint™ under you, you might be able to save some weight and travel with a lighter sleeping bag or blanket.



2. **Moki™ Footprint:** The Footprint is a 70D abrasion-resistant nylon fabric ground sheet perfectly sized to fit underneath your Moki™ tent. The fabric is PU coated for waterproofness. The Footprint reduces wear and tear on your tent floor from contact with the ground.



3. **Moki™ Link™:** Enhance the living space between two Moki™ tents with the Moki™ Link™. Whether used as a communal meeting space, versatile entrance, sleeping area for pets, or covered storage for your gear, the Moki™ Link™ is sure to become a favorite accessory for all trips and adventures. Featuring dual entrances, a floorless interior, and a ceiling vent, the Link™ gives you unprecedented flexibility when extra space is needed. The Link™ is held securely in place by two vestibule poles and a snow skirt for winter conditions. The total weight is 2.4 lbs.



4. **Moki™ APRI™:** The Moki™ APRI™ is built for the most brutal conditions on the planet. The APRI™ is made from a metallized fabric laminate that substantially increases the temperature inside the tent. Totally breathable, the APRI™ allows you to function comfortably inside your tent (but outside your sleeping bag) when the mercury drops. Moki™ APRI™ is held securely in place by the two internal poles and Velcro® straps. The total weight is 2.6 lbs.

