
DISCO™ PAD PUMP

The latest plush air-filled sleeping pads are great for sleeping, but tough to inflate with your lungs. Disco™ is here to save the night. One good breath blows up the outer frame of the pump, making the pump springy, and then with a little dance your pad is inflated in no time. Disco™ weighs only 2.2 ounces and can be rolled right up with your pad or kept in its lemon-sized stuff sack.

Setup Instructions

Inflate Pump: Twist and pull open valve and blow into pump until firm. While blowing, push valve in to seal and twist to lock. Pump must be firm.



Inflate Pad: With pump on the ground, make a good seal over hole on top of pump and press down. Make sure pad valve remains open and connected. Lift your hand away and repeat until pad is inflated.







Care and Repair / Warranty

NEMO guarantees every product we sell. We put a great effort into choosing the best materials and providing you with the highest level of workmanship. NEMO products carry a lifetime warranty against defects in workmanship and materials to original owner, with proof of purchase.NEMO does not warranty products against normal wear and tear, unauthorized modifications or alterations, improper use, improper maintenance, misuse or neglect or if the product is used for a purpose for which it is not intended. If you are having a problem with your NEMO product, please visit www.nemoequipment.com/tent-manufacturer-warranty or call NEMO Customer Service at 1-800-997-9301.

814041011136

INSTRUCTIONS FOR USE



Use black valve to inflate pump. Twist counterclockwise to open, clockwise to close when firm.



Attach pump to pad by inserting pad valve into the opening on side of pump. Make sure valve on pad is open to allow air to flow in.



With pump on ground, place hand over hole and press down repeatedly until pad is firm. You may want to top off pad with mouth.



DISCO™ PAD PUMP